

8. Level 3 Repair


آموزش شماتیک و نقشه خوانی

iranbsm.ir


8-1. Components Layout


PBA (TOP)

Mobile schematic training





PBA BOTTOM







8. Level 3 Repair








8. Level 3 Repair



8. Level 3 Repair




Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.

8. Level 3 Repair

8-2. Flow chart of Troubleshooting.


	
<p>Oscilloscope</p>	<p>Digital Multimeter</p>
	
<p>Power Supply</p>	<p>+ driver, ESD Safe Tweezer</p>
	
<p>8960 & Spectrum Analyzer</p>	<p>Soldering iron</p>

8. Level 3 Repair

8-3-1. No Power No Power

Step	Check point	Result value	Defect point
1	Confirm the defect symptom. (Do not confuse the screen problem.)	-	-
2	Check the Power button working physically	Normal	Go to the step 3
		Get Stuck / Sticky	Cleaning, Reassembly
3	Can USB charge normally ?	Yes	Go to the step 3.1
		No	Replace the battery
3.1	Can start the machine normally after charging ?	Yes	Cell phone under voltage, c ontinue charging
		No	Go to the step 4
4	Check the voltage level at Vbat and GND these t wo points is greater than 3.6V	Yes	Go to the step 5
		No	Replace the battery
5	Check the output voltage of U1000, C1536=0.8 V, C1539=0.8V, C1519=0.8V, C1544=0.8V	If the output voltage is not normal, Change the U1400	

No Power (cont')




8. Level 3 Repair

8-3-2. Charging No Charging

Step	Check point	Result value	Defect point
1	Confirm the defect symptom	-	-
2	Replace a battery.	Solved	Go to the step 2.1
		Not solved	Go to the step 3
2.1	Charge the customer battery during 5min at least.	Solved	Totally discharged battery
		Not solved	Go to the step 3
3	Disassemble and check I/F connector visually	Dust	Clean I/F connector
		Damage	Replace I/F connector
		Normal	Go to the step 4
4	Check the VBUS_USB_IN(C1312)=5V	C1312 = 5V	Go to the step 6
		If not the correct value	Replace U2401
5	Battery is Charging <u>nomal</u>	No	Replace U1301
6	Check whether the voltage at both ends of C13 15 capacitor is greater than 3.6V	If the output voltage is not normal, Change the U1301	

No Charging




8. Level 3 Repair

8-3-3. Call problem

Call Problem (with RF test equipment)


Step	Check point	Result value		Defect point
1	Confirm the defect symptom	-		-
2	RF radiation test	Pass		Network or Settings
		Fail		Go to the next step
3	RF calibration	Pass		Go to the step 4
		Fail		Go to the step 5
4	RF radiation test	Pass		Repaired
		Fail		Except PBA (Coaxial cable, Antenna, Shielding condition)
5	A type of failure	TX	2G	TXM(U3201) TRANSCEIVER(U3001)
			3G/LTE	PA(U3101) TXM(U3201) TRANSCEIVER(U3001)
		RX	2G	TRANSCEIVER(U3001) TXM(U3201)
			3G/LTE	TRANSCEIVER(U3001) TXM(U3201)

Call Problem



8. Level 3 Repair

- The main RF chips are mt6177m (U3001), L / M / h PA (U3101, U3201)



Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.


8. Level 3 Repair

Call Problem (without RF test equipment)


Step	Check point	Result value	Defect point
1	Confirm the defect symptom	-	-
2	Check the settings (airplane mode, Mobile networks)	Abnormal	Settings
		Normal	Go to the next step
3	Check the signal strength of the device. Settings-> About phone->SIM status->Signal strength. (Compare to normal device)	Abnormal	Go to the next step
		Normal	Network
4	Check the RF parts except PBA. (Coaxial cable, Antenna, Shielding condition, etc..)	Broken, dust, corrosion	RF parts
		Loose fitting	Connection
		Normal	Go to the next step
5	Check the status visually(crack, missing, Corrosion..etc) of RF components. (compare to normal PBA)	Abnormal	4G PA MMBPA (U3101) 2G PA TXM(U3201) TRANSCIEVER(U3001)
		Normal	CP(Call Processor) (U1600) PMIC(U1400)

Call Problem


Step2 **CHECK SETTINGS**




Step3



Signal strength Same value compare to normal device.







Step4



8. Level 3 Repair

Call Problem

Step5




8. Level 3 Repair

Sound Problem

Step.	Check point	Result value	Defect point
1	Confirm the defect symptom.	-	-
2	*#88*# → speaker	No sound	Go to the next step
		Normal	S/W or Settings
3	Replace the speaker, and also replace the <u>Assy</u> case-rear to use a new speaker tape.	Solved	speaker
		Not solved	Go to the next step
4	Activate the speaker path. (*#0*# → Speaker)	-	-
5	Check C-clips of Sub PBA ANT201,ANT202	normal	Go to step 6
		defect	Replace C-Clip
6	Check the PWM output at ANT201	Yes	Go to step 7
		No	Replace Link FPCB
7	Check the PWM output at ANT201	Yes	Go to step 8
		No	Replace SUB PBA
8	Check the PWM output at U2501	Yes	Replace speaker module
		No	Replace U2501 on MAIN PCB

Sound Problem



Confidential and proprietary-the contents in this service guide subject to change without prior notice

Distribution, transmission, or infringement of any content or data from this document without Samsung's written authorization is strictly prohibited.


8. Level 3 Repair

8-3-5. Display Problem

Display Problem

Step	Check point	Result value	Defect point
1	Confirm the defect symptom	-	-
2	Check the LCD connector (J2004)	Broken, dust, corrosion	LCD connector (J2004)
		Loose fitting	Connection
		Normal	Go to the next step
3	Replace the LCD	Solved	LCD
		Not solved	Go to the next step
4	Connect a LCD, and display on with a power supply (power supply voltage : 4.0V)	-	-
5	Check LCM_AVDD = 6.0V (C2024) LCM_AVEE = -6.0V (C2023)	No	Replace the U2201
		Yes	Go to step 6
6	Check LCD_LEDA = 22V (C2040) LCD_LEDK = 0.2(C2038)	No	Replace the U2002, L2002, D2001
		Yes	Replace the Display module

Display Problem



8. Level 3 Repair

8-4. Service Schematics

■ U1400_BB chip IC , Digital Baseband Processor(Top)

2.2FCBGA Pinout

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19
A	NC	EXT_XTL_ENT	FB_WP_A	VBAT_DRV_1	LX_W_PA	LX_SRA_M	VBA_TDR_V_1	ADL_D	AUD_DA_SYN_C		AUD_SC_LK	VSS_DRV	LX_M_ODE_M	VBA_TDR_V_3	VBA_TDR_V_3	LX_C_ORE	VSS_DRV	VSS_DRV	NC
B	EXT_XTL_EN2	T_DI_G	FB_WP_A	VBAT_DRV_1	LX_W_PA	LX_SRA_M	VBA_TDR_V_1	AUD_DADO	AUD_AD_SYN_C	DCD_C_CP_U_EN	AUD_AD_DO	VSS_DRV	LX_M_ODE_M	VBA_TDR_V_3	VBA_TDR_V_3	LX_C_ORE	VSS_DRV	VSS_DRV	VSS_DRV
C	EXT_XTL_EN0	EXT_XTL_EN3					FB_SRA_M	ADL_SCLK			CHP_S_LEE_P	VSS_DRV	LX_M_ODE_M	VBA_TDR_V_3	LX_C_ORE			LX_C_PU	LX_C_PU
D	VSS_DRV_BST	VSSD_RV_BST	SPK_N	VSS_PA	SPK_P			DCD_C_GP_U_EN		ANA_INT	EXT_RS_T_B						LX_CPU	VBA_TDR_V_3	VBA_TDR_V_3
E	LX_BST	LX_BST		VSEN_P	IVSEN_N	ISEN_P		VSSD_RV	AUD_DA_D1	CLK3_2K	PTE_STO	FB_MOD_EM		FB_CO_RE_N			VBA_TDR_V_3	VBA_TDR_V_3	VBA_TDR_V_3

V.0.2

Spreadtrum Communications, Inc., Confidential and Proprietary

15 of 928

This document contains information on a product under development.
 Spreadtrum reserves the right to change or discontinue this product without notice.



UMP510G Device Specification

F	VBA_T_BS_T	VBAT_BST			VBST_PA			VSSD_RV	WPA_AP_CIN			FB_MOD_EM_N		FB_CO_RE	FB_CPU_N	FB_CPU	VBA_TDR_V_3	LX_GPU	LX_GPU
G	MIC2_BIA_S	MIC2_N			VBST_PA			VSSD_RV									LX_GPU	VSS_DRV	VSS_DRV
H		MIC2_P	MIC1_B_IAS	HEAD_SET_L_INT	GND_DET	AGN_D_A_NA1	AGN_D_A_NA2	VSS			VSS	VSS			FB_GPU_N	FB_GPU	VSS_DRV	VSS_DRV	VSS_DRV
J	AVD_D_V_B	HEA_DMIC_BIA_S		HEAD_MIC_I_N_DE_T	HEAD_MIC_N	AGN_D_V_B	MIC1_P	VSS	DPIN	DMIN		VBA_TB	PROD_T			VPP		LX_MEM	LX_MEM
K	CP_CAF_P	CP_C_AP_N	VBAT_AU_D		HEAD_MIC_P		MIC1_N	VSS	SPO_UT	DMO_UT	VCH_G	VBA_T_SE_NSE				PBIN_T	VBA_TDR_V_2	VBA_TDR_V_2	VBA_TDR_V_2
L		VDD_CG_GEN1		VDD_CP		VSS				VSS	CHG_PD	BAT_DET	SENS_E_P	SENSE_N		FB_MEM		LX_MEM_Q	LX_MEM_Q
M	VNE_G_C_P	VDD_CG_GEN0	RC_V_P	RCV_N	HP_R	DNS_D0	DNS_D1						EXTR_STN		PBIN_T2	FB_MEM_Q	VSS_DRV	VSS_DRV	VSS_DRV
N		AMP_G_VC_OM	HP_L				CLK20M										VBA_TDR_V_2	LX_GEN1	LX_GEN1
P	VNE_G_D_RV	CC1				VSS		VBAT_A	VBA_TA		VBA_TA	VBA_TA				VDC_DC_GEN1		VBA_TDR_V_2	VBA_TDR_V_2
R		CC2	SW	OPTIO_N3	OPTI_ON4	OPTI_ON1	VDD_NN	VDDL_D00	VDD_VIB		VBA_TA	RGB_IB0	YDDC_AMO	ADC_I1				LX_GEN0	LX_GEN0
T	VSS_TSX_B	VSS_TSX_A	REF_OUT3	VSS_T_SX_A	OPTI_ON2	VBA_T_B_K	VDD_RTC		VDD_LDO1	VDD_USB3_3	RGB_IB1	RGB_IB2		ADC_I4	ADC_I5			VSS_DRV	VSS_DRV
U		REF_OUT0	REF_OUT2	VSS_T_SX_A	DCX0_LOW_CUR		OPTI_ON5		VDD_CAM_A1		VDD_KPL_ED		ADC_I2	ADC_I3	VDB_GA_MD1	VDB_DC_GEN0	VDB_DC_GEN0	VDB_DC_GEN0	
V	REF_OUT1	VSS_TSX_A	REF_OUT4	YSEN_VRE_FN	TSEN_IN	RTC_32K_K0	OPTI_ON5	VDD5_IM1	VDD_SIM0	VDDL_D02	VDD_28	VDD_SIO	VDD_SIO	VDD_MMC_CORE	VDD_WFI_PA	AVD_D18	VDD_RF18	AVD_D12	VDD_WCN
W	NC	XO_N	XO_P		TSEN_VRE_FP	RTC_32K_K1		VDD1_8_DC_X0	VDD_SIM2		VDD_CAM_A0		YDDC_AMM_OT		VDD_SOC_ORE	VDD_RF1_V2S	VDD_GAM_D0		NC