



8-3. Flow chart of Troubleshooting.





Oscilloscope




Digital Multimeter



Power Supply



+ driver, ESD Safe Tweezer




8960 & Spectrum Analyzer




Soldering iron


8-4-1. Power On




8-4-2. Initial



8-4-3. No Service




8-4-4. Sim Part




Normal case's Impedance

SIM	C5	C1	C6	C2	C7	C3
#1	SHORT	1.3M	OPEN	6.2M	6.7M	6.5M
#2	SHORT	0.9M	OPEN	6.2M	7.1M	6.5M
#3	SHORT	1M	OPEN	6.3M	6.6M	6.2M




PIN No.	Name		
C1	Vcc		
C2	RST		
С3	CLK		
C4	Reserved		
C5	GND		
C6	Vpp		
C7	1/0		
C8	Reserved		


8-4-5. Charging Part




8-4-6. Accel Sensor




8-4-7. Speaker Part




8-4-8. Receiver Part



8-4-9. LCD




8-4-10. TSP




8-4-11. 5M CAMERA






8-4-12. VGA CAMERA

.




8-4-13. Flash LED


.




8-4-14. WCDMA B1 / LTE B1 RX




8-4-15. GSM1900 RX




8-4-16. GSM1800 / LTE B3 Rx




8-4-17. GSM850 / WCDMA B5 / LTE B5 RX




8-4-18. LTE B7 RX




8-4-19. GSM900 / WCDMA B8 / LTE B8 Rx




8-4-20. LTE B20 RX




8-4-21. LTE B40 RX




8-4-22. GSM850 / GSM900 TX




8-4-23. GSM1800 / GSM1900 TX




8-4-24. WCDMA B1 / LTE B1 TX




8-4-25. LTE B3 TX




8-4-26. WCDMA B5 / LTE B5 TX




8-4-27. LTE B7 TX




8-4-28. WCDMA B8 / LTE B8 TX




8-4-29. LTE B20 TX




8-4-30. LTE B40 TX




8-4-31. BT/WLAN



8-4-32. GPS



8-4-33. FM RADIO



8-5. Service Schematics

- NC Point(Top View) U3000 (AP)

